


Bike	Triumph Trident 660	Part No.	RTR-91-SYS
Year	2021-Current	Fit Kit	Z039.10697
Notes	Where not supplied use original fittings	dB Killer	SCEXDBK23 (TYPE V)


Estimated Fitting Time: 60 Minutes



NO.	PART NO.	DESCRIPTION	QTY
1	RSC231	Serket Taper Silencer	1
2	CP1122	L/H Header Pipe	1
3	CP1123	Centre Header Pipe	1
4	CP1124	R/H Header Pipe	1
5	CP1125	Collector	1
6	CP1126	Connecting Pipe	1
Fit Kit - Z039.10583			
7	Z017.10047	M8 x 25mm Hex Head Bolt	1
8	Z017.10825	M8 x 25mm Washer	2
9	Z015.31434	Mounting Bracket	1
10	Z017.10075	M8 x 35mm Cap Head Bolt	1
11	Z028.10030	Rubber Coated Spring	7
12	Z007.31692	Header Flange	3
13	Z026.20336	Header Collar	3


E-MARK	BSAU 193a 1990/T3
DATE	22/07/21
ISSUE	00
AUTHORISED	M.Ydlibi

NOTE: ENSURE SCORPION SYSTEM IS CLEAR OF MOVING PARTS AND ALL ORIGINAL FUNCTIONS WORK CORRECTLY.




STAY CONNECTED TO RED POWER.

Bike	Triumph Trident 660	Part No.	RTR-91-SYS
Year	2021-Current	Fit Kits	Z039.10697
Notes	Where not supplied use original fittings	dB Killer	SCEXDBK23 (TYPE V)





A) Remove the lambda sensor from the original exhaust.



B) Loosen the radiator top mount. Do not fully remove the bolt.

C) Remove the bolt on the radiator support bracket. This will allow the radiator to rock forward giving you more room to remove the header nuts.

D) Un-bolt the 6 header nuts.



E) Remove the left hand rear silencer mounting bolt.

F) Support the weight of then exhaust then remove the right hand rear silencer mounting bolt. The original exhaust should now come off the bike.


G) Bolt the collars to the engine ports using the flanges. Ensure the holes on the outside flanges are to the bottom and the holes on the middle flange is to the top.



H) Loosely bolt the mounting bracket to the right side original mounting point.



Bike	Triumph Trident 660	Part No.	RTR-91-SYS
Year	2021-Current	Fit Kits	Z039.10697
Notes	Where not supplied use original fittings	dB Killer	SCEXDBK23 (TYPE V)



I) Starting from the left side fit the header pipes over the collars and secure them with the spring.

J) Fit the 3 in to 1 collector over the three header pipes.

K) Fit the connecting pipe to the collector.

L) Fit the silencer on to the collector and loosely bolt it to the mounting bracket.

M) Starting from the front of the bike and working your way back fit the rest of the springs to the to the system.

N) Fully tighten the two bolts on the mounting bracket.

O) Re-fit the radiator support bracket and tighten the bolt on the top mount.

P) Re-fit the lambda sensor in to the Scorpion system.

When fitted take bike for a short ride to ensure all functions are correct. When bike & exhaust are cool enough check all nuts and bolts are still secure.



Bike	Triumph Trident 660	Part No.	RTR-91-SYS
Year	2021-Current	Fit Kit	Z039.10697
Notes	Where not supplied use original fittings	dB Killer	Z038.10043 (TYPE V)

Estimated Fitting Time: 60 Minutes



Thank you for purchasing your Scorpion Silencer.

Care of your exhaust: Please refrain from cleaning silencer with heavy solvents or abrasives!

Vielen Dank Für den kauf eines Scorpion Schalldampfers! Pflegehinweis: Bitte verwenden Sie niemals Scheuermittel oder aggressive Reiniger zur Pflege Ihres Auspuffes!

Merci d'avoir choisi un echappement Scorpion.

Entretien de votre silencieux: Ne pas utiliser de solvants ou de produits abrasifs!

“Muchas gracias por adquirir un Silencioso Scorpion. Le recomendamos no limpiar el silencioso con productos abrasivos o aquellos que contengan disolventes.”



STAY CONNECTED TO RED POWER.